

# ARLEN NESS KO 7° RAKED TREE KIT

Part# 20-389

Fits: 2014-Later HD FLT and FLH Models



Thank you for purchasing this Arlen Ness product. We believe that our products are the very best available and are engineered to provide a lifetime of use. ***This installation must be performed by a qualified motorcycle technician to ensure proper installation.***

Parts:	7- 3/8" AN Washers
1- Top Triple Tree	7- 3/8-16 x 1 1/2" Socket Head Bolts
1- Bottom Triple Tree	1- 20389-I Triple Tree Instructions
2- 49mm Travel Limiters	1- LIMIT-I Travel Limiter Instructions
1- Tube Blue Thread Locker	1- Nacelle20389-I template

## IMPORTANT NOTE:

### **DO NOT LOWER FORKS, STANDARD FORK LENGTH ONLY. DO NOT USE WITH TOUR PACK.**

On all applications we recommend a Goodridge brake line kit, part number will vary based on handlebar height/pullback and model.

1. Remove fairing, fork, and tree assembly per the appropriate service manual of your model motorcycle.
2. Refer to instruction sheet Limit-I to install neoprene Travel Limiter for your specific wheel and fender combination. NOTE: DO NOT LOWER FORKS, STANDARD FORK LENGTH ONLY.
3. \*\*\*\*\*2015-Up Road Glide models only. When re-installing the gauge nacelle you will need to trim the shaded area of the templates on the following page. Pictures are shown below of template placement. Use same template for both sides of the nacelle.
4. Install forks and fairing per the appropriate service manual of your model motorcycle. Note: The seven OEM triple tree pinch bolts are 5/16" diameter. The 20-389 features 3/8-16 pinch bolts. Install one 3/8 AN washer on each bolt, add a drop of blue thread locker and install the seven pinch bolts and **torque to 25 ft/lbs.**

6050 Dublin Boulevard, Dublin, Ca. 94568 Technical Assistance : 925.479.6379— [www.arlenness.com](http://www.arlenness.com) 20389-I rev 02-24-2014

